





supremo[®]

LEISURE



Parts list:

No.	Picture	Name	Qty
A		Cover	1
B		Back Frame	1
C		Front Frame	1
D		Side Frame	2
E		Bottom Frame	1
F		Bolt Cover	17
G		Bolt (40mm)	14
H		Bolt (45mm)	3
I		Steel Washer	20
J		PVC Nut Cover	3
K		Nut	3
L		Nut Wrench	1
M		Wrench	1

Assembly Instruction



(1) (2)
(3) (4)



GLA-60376-36KD